



| №    | Артикул          | Наименование                | Кол-во |
|------|------------------|-----------------------------|--------|
| 1    | 8313-438801EVO   | Bar Adjustment Locking Knob | 1      |
| 2    | 8440-439501EVO   | Cover Assembly              | 1      |
| 2-1  | 8334-463101EVO   | Axle Bushing                | 1      |
| 2-2  | 8021-439501EVO   | Cover                       | 1      |
| 2-3  | 8208-438801EVO   | Sealing Ring                | 1      |
| 3    | 8CE-07BEVO       | Retaining Ring              | 1      |
| 4    | 8128-462202EVO   | Sprocket                    | 1      |
| 5    | 8342-462304EVO   | Spring                      | 1      |
| 6    | 8208-438301EVO   | Sealing Ring                | 1      |
| 7    | 8SNAB29-12DEVO   | Self-tapping Screw          | 2      |
| 8    | 8SJAB40-16EVO    | Self-tapping Screw          | 29     |
| 9    | 8202-438801EVO   | Insulation Gasket           | 1      |
| 10   | 8440-491105EVO   | Adjusting Rod Assembly      | 1      |
| 11   | 8313-436501EVO   | knob                        | 1      |
| 12   | 8SJAB40-30DEVO   | Self-tapping Screw          | 2      |
| 13   | 8181-481601EVO   | Buffer Board                | 1      |
| 14   | 8006-439502EVO   | Right Housing               | 1      |
| 15   | 8440-438408EVO   | Oil Tank Cap Assembly       | 1      |
| 15-1 | 8024-432101EVO   | Oil Tank Cap Cover          | 1      |
| 15-2 | 8020-431701EVO   | Oil Tank Cap                | 1      |
| 15-3 | 8208-431901EVO   | Sealing Ring                | 1      |
| 15-4 | 8088-438401EVO   | Hook                        | 1      |
| 16   | 8440-439504EVO   | Oil Tank Assembly           | 1      |
| 16-1 | 8165-439501EVO   | Oil Tank                    | 1      |
| 16-2 | 8342-437501EVO   | Spring                      | 1      |
| 16-3 | 8208-462503EVO   | Sealing Ring                | 1      |
| 16-4 | 234-1003EVO      | Translucent Oil Tube        | 0.19m  |
| 16-5 | 8335-481201EVO   | Valve                       | 1      |
| 16-6 | 8341-491801EVO   | Rubber Cushion              | 1      |
| 17   | 8024-438401EVO   | Dust Cover                  | 1      |
| 18   | 8334-439501EVO   | Axle Bushing                | 2      |
| 19   | 8321-439501EVO   | Braking Pad                 | 1      |
| 20   | 8342-435302EVO   | Brake spring                | 1      |
| 21   | 8087-438401EVO   | Switch Link Rod             | 1      |
| 22   | 8182-471902EVO   | Pressboard                  | 1      |
| 23   | 8342-481501EVO   | Spring                      | 1      |
| 24   | 8440-467608EVO   | Oil Nozzle Set              | 1      |
| 25   | 8202-462203EVO   | Brake washer                | 1      |
| 26   | 234-1003EVO      | Translucent Oil Tube        | 0.07m  |
| 27   | 8182-439501EVO   | Pressboard                  | 1      |
| 28   | 8304-438401EVO   | Positioning Block           | 1      |
| 29   | 8042-481603EVO   | Micro Switch                | 1      |
| 30   | 8SJAB30-16DEVO   | Self-tapping Screw          | 1      |
| 31   | 8087-438402EVO   | Intermediate Link Rod       | 1      |
| 32   | 8312-439401EVO   | Switch Button               | 1      |
| 33   | A013025-031EVO   | Switch Torsion Spring       | 1      |
| 34   | 8342-440302EVO   | double Torsion Spring       | 1      |
| 35   | 8312-433501EVO   | Anti-self-locking Button    | 1      |
| 36   | 8416-000006EVO   | Two-pin Capacitor           | 1      |
| 37   | 8184-282102EVO   | Cord Pressboard             | 1      |
| 38   | 8411-522201EVO   | Terminal Set                | 2      |
| 39   | 8422-431701EVO   | Power Cord & Plug           | 1      |
| 40   | 8332-491901EVO   | Cable Sheath                | 1      |
| 41   | 8006-439501EVO   | Left Housing                | 1      |
| 42   | 8440-439502EVO   | Output Shaft Assembly       | 1      |
| 42-1 | 8BC-221006-STEVO | 6900 Bearing                | 1      |
| 42-2 | 8085-434501EVO   | Output Shaft                | 1      |
| 42-3 | 8342-435301EVO   | Brake Torsion Spring        | 1      |
| 42-4 | 8063-462201EVO   | Axle Bushing                | 1      |
| 42-5 | 8123-471301EVO   | Output Shaft Gear           | 1      |
| 42-6 | 8BC-220807-STEVO | 608Z Bearing                | 1      |
| 42-7 | 8NH-08DEVO       | Hexagon Lock Nut            | 1      |
| 43   | 8440-435325EVO   | Oil Pump Assembly           | 1      |
| 43-1 | 8342-491201EVO   | Oil Pump Extension Spring   | 1      |
| 43-2 | 8440-481614EVO   | Oil Pump                    | 1      |
| 44   | 8SNAB29-12EVO    | Self-tapping Screw          | 2      |
| 45   | 8302-439501EVO   | Adding Weight Piece         | 2      |
| 46   | 8185-439501EVO   | Front Hand Guard            | 1      |
| 47   | 8003-439501EVO   | Front Handle                | 1      |
| 48   | 8440-439505EVO   | Motor Assembly              | 1      |
| 48-1 | 8440-439517EVO   | Stator Assembly             | 1      |
| 48-2 | 8440-439518EVO   | Rotor Assembly              | 1      |
| 48-3 | 8440-438407EVO   | Brush holder Assembly       | 1      |
| 48-4 | 8SJAB25-08DEVO   | Self-tapping Screw          | 2      |
| 49   | 8004-439501EVO   | Motor Rear Bracket          | 1      |
| 50   | 8413-433401EVO   | Connection Wire             | 1      |
| 51   | 8413-690902EVO   | Connection Wire             | 1      |
| 52   | 8413-467402EVO   | Connection Wire             | 2      |
| 53   | 239-0011EVO      | Female Terminal             | 3      |
| 54   | 239-0044EVO      | Copper Tape                 | 24mm   |
| 55   | 233-1006EVO      | Heat Shrink Tube            | 0.15m  |
| 56   | 243-0168EVO      | Guide Bar                   | 1      |
| 57   | 243-0102EVO      | Saw Chain                   | 1      |
| 58   | 8331-462101EVO   | Bar Sheath                  | 1      |
| 59   | 233-1004EVO      | Heat Shrink Tube            | 0.12m  |