



№	Артикул	Наименование	Кол-во
1	8313-438801EVO	Bar Adjustment Locking Knob	1
2	8440-439501EVO	Cover Assembly	1
2-1	8334-463101EVO	Axle Bushing	1
2-2	8021-439501EVO	Cover	1
2-3	8208-438801EVO	Sealing Ring	1
3	8CE-07EVO	Retaining Ring	1
4	8128-462202EVO	Sprocket	1
5	8342-462304EVO	Spring	1
6	8208-438301EVO	Sealing Ring	1
7	8SJGB30-08EVO	Self-tapping Screw	2
8	8SJAB40-16EVO	Self-tapping Screw	31
9	8202-438801EVO	Insulation Gasket	1
10	8440-491105EVO	Adjusting Rod Assembly	1
10-1	8087-491301EVO	knob	1
10-2	8207-491301EVO	Tighten nut	1
10-3	8207-491302EVO	nut	1
11	8313-436501EVO	knob	1
12	8SJAB40-30EVO	Self-tapping Screw	2
13	8181-481601EVO	Buffer Board	1
14	8006-439502EVO	Right Housing	1
15	8341-491801EVO	Rubber pad	1
16	8440-438408EVO	Oil Tank Cap Assembly	1
16-1	8024-432101EVO	Oil Tank Cap Cover	1
16-2	8020-431701EVO	Oil Tank Cap	1
16-3	8208-431901EVO	Sealing Ring	1
16-4	8088-438401EVO	Hook	1
17	8440-439502EVO	Oil Tank Assembly	1
17-1	8165-439501EVO	Oil Tank	1
17-2	8342-437501EVO	Spring	1
17-3	8208-462503EVO	Sealing Ring	1
17-4	234-1003EVO	Translucent Oil Tube	0.19m
18	8024-438401EVO	Dust Cover	1
19	8334-439501EVO	Axle Bushing	1
20	8321-439501EVO	Braking Pad	1
21	8342-435302EVO	Brake spring	1
22	8414-439501EVO	soft start	1
23	8440-438402EVO	Switch Link Rod Assembly	1
24	8182-471902EVO	Pressboard	1
25	8342-481501EVO	Spring	1
26	8440-467608EVO	Oil Nozzle Set	1
27	8202-462203EVO	Brake washer	1
28	234-1003EVO	Translucent Oil Tube	0.07m
29	8182-439501EVO	Pressboard	1
30	8304-438401EVO	Positioning Block	1
31	8042-481601EVO	Micro Switch	1
32	8SJAB30-16EVO	Self-tapping Screw	11
33	8087-438402EVO	Intermediate Link Rod	1
34	8312-439401EVO	Switch Button	1
35	8342-432101EVO	Switch Torsion Spring	1
36	8342-463002EVO	Push button Spring	1
37	8312-433501EVO	Anti-self-locking Button	1
38	8416-000006EVO	Two-pin Capacitor	1
39	8184-282102EVO	Cord Pressboard	1
40	8411-522201EVO	Terminal Set	1
41	8422-430201-01EVO	Power Cord & Plug	1
42	8332-491901EVO	Cable Sheath	1
43	8006-439501EVO	Left Housing	1
44	8440-439502EVO	Output Shaft Assembly	1
44-1	8BC-221006-STEVO	6900 Bearing	1
44-2	8085-434501EVO	Output Shaft	1
44-3	8342-435301EVO	Brake Torsion Spring	1
44-4	8063-462201EVO	Axle Bushing	1
44-5	8123-471301EVO	Output Shaft Gear	1
44-6	8BC-220807-ST03EVO	608Z Bearing	1
44-7	8NH-08EVO	Hexagon Lock Nut	1
45	8440-435325EVO	Oil Pump Assembly	1
45-1	8342-491201EVO	Oil Pump Extension Spring	1
45-2	8440-481614EVO	Oil Pump	1
46	8SNAB29-12EVO	Self-tapping Screw	2
47	8440-439504EVO	Front Guard Assembly	1
47-1	8302-439501EVO	Adding Weight Piece	2
47-2	8185-439501EVO	Front Hand Guard	1
48	8003-439501EVO	Front Handle	1
49	8440-439507EVO	Motor Assembly	1
49-1	8NH-04EVO	Hexagon Lock Nut	2
49-2	8182-438401EVO	Windshield	1
49-3	8NG-08EVO	Hexagon Flange Nut	1
49-4	8123-481004EVO	Motor Gear	1
49-5	8333-462203EVO	Motor Gear Bushing	1
49-6	8BC-301009-SS20EVO	Bearing 6200-2RS	1
48-7	8402-481605EVO	Rotor Assembly	1
49-8	8BC-220807-STEVO	Bearing 608Z	1
49-9	8333-211001EVO	Bearing Bushing	1
49-10	8405-481005EVO	Stator Assembly	1
49-11	8291-438402EVO	Rear Bracket	1
49-12	8440-439607EVO	Carbon Brush Holder Assembly	2
49-13	8206-481003EVO	Stator Screw	2
49-14	8SJGB30-08EVO	Self-tapping Screw	2
50	8004-439501EVO	Motor Cover	1
51	8413-433401EVO	Connection Wire	1
52	8413-690902EVO	Connection Wire	1
53	8413-481005EVO	Connection Wire	3
54	8413-467402EVO	Connection Wire	1
55	239-0011EVO	Female Terminal	3
56	239-0044EVO	Copper Tape	24mm
57	233-1006EVO	Heat Shrink Tube	0.15m
58	243-0173EVO	Guide Bar	1
59	243-0077EVO	Saw Chain	1
60	8331-462101EVO	Bar Sheath	1
61	233-1004EVO	Heat Shrink Tube	0.12m