


№	Артикул	Наименование	Кол-во
1	4.009.0012.13EVO	Flywheel Assy	1
2	5.06.01.03101EVO	3.0x3.7x10 Key	1
3	5.02.10.08011EVO	Hexagonal nut M8X1	1
4	5.09.02.12225EVO	Small oil seal 12X22X5	1
5	5.08.03.12282EVO	Bearing 6001-2RSW	2
6	5.09.02.12286EVO	Big oil seal 12X28X6	1
7	5.01.07.05221EVO	M5X22 Screw	4
8	4.003.0012.29EVO	Crankshaft	1
9	4.004.0051.12EVO	Grinding pad	2
10	5.08.08.08111EVO	K8*11*8.5 Roller pin&the holder Assy	1
11	4.004.0041.18EVO	Piston pin ring	2
12	4.004.0031.19EVO	Piston pin	1
13	4.004.0013.30EVO	Piston	1
14	4.004.0021.24EVO	Piston ring	1
15	4.002.0031.08EVO	Crankcase bearing seat	1
16	4.002.0011.51EVO	Cylinder	1
17	4.005.0023.19EVO	Intake tube	1
18	4.009.0041.05EVO	Sparking Plug L7T	1
19	4.018.0021.64EVO	Heat Insulated pad	2
20	4.009.0023.35EVO	Ignition Assy	1
21	5.01.07.05201EVO	M5X20 Screw	2
22	4.009.0031.31EVO	Flameout cord	1
23	4.014.0041.10EVO	Oil pump pipe (In)	1
24	4.014.0022.05EVO	Oil filter	1
25	4.014.0161.04EVO	Dust proof sponge	1
26	4.014.0011.13EVO	Oil pump	1
27	5.01.06.04121EVO	M4X12Screw	4
28	4.014.0051.10EVO	Oil pump pipe (Out)	1
29	4.014.0023.03EVO	Oil pump cover	1
30	5.01.03.39101EVO	ST3.9X10 Screw	10
31	4.014.0171.04EVO	Worm gasket	1
32	4.014.0063.10EVO	Worm	1
33	5.08.08.101313EVO	K10*13*13 Roller pin&the holder Assy	1
34	4.010.0043.18EVO	Clutch passive disk	1
35	4.010.0051.10EVO	Flying hammer grinding pad	1
36	4.010.0012.04EVO	Clutch Assy	1
37	4.010.0011.05EVO	Clutch wedge	2
38	4.010.0021.06EVO	Wedge bracket	1
39	4.010.0031.04EVO	Cluth Spring	2
40	4.019.0031.17EVO	Muffler gasket	1
41	4.006.0012.43EVO	Muffler	1
42	4.006.0031.05EVO	Muffler spacer plate	1
43	5.01.07.05501EVO	M5X50 Screw	4
44	4.007.0022.01EVO	Breather Assy	1
45	4.007.0041.85EVO	Breather pipe	1
46	4.014.0151.01EVO	Circlip	1
47	4.014.0161.01EVO	Sponge	1
48	4.014.0101.01EVO	Breather valve	1
49	4.007.0161.01EVO	Fuel pump Assy	1
50	3.001.0013.14EVO	Engine cover Assy	1
51	3.001.0091.38EVO	Upper cover plate	1
52	4.019.0051.04EVO	Anti-oil paper pad	1
53	4.014.0081.10EVO	Guide plate	1
54	4.014.0161.05EVO	Guide plate sponge	1
55	5.01.16.48162EVO	The shock absorption screw	4
56	3.001.0461.06EVO	Chain catcher	1
57	4.013.0021.68EVO	Dumper	3
58	3.001.0641.12EVO	Dumper cap	3
59	4.018.0091.05EVO	Pothook	1
60	4.007.0012.05EVO	Fuel filter Assy	1
61	4.007.0041.86EVO	Fuel pipe	1
62	4.007.0061.06EVO	Fuel pipe connection	2
63	4.007.0041.87EVO	Carburetor pipe	2
64	4.007.0041.88EVO	Fuel pump return pipe	1
65	3.002.0024.15EVO	Tank cap Assy	2
66	3.001.0272.04EVO	Tank cap	2
67	4.007.0101.05EVO	Airproof washer	2
68	3.001.0291.05EVO	Tank cap hanger	2
69	5.01.07.05181EVO	M5X18 Screw	5
70	5.01.02.42652EVO	ST4.2X6.5 Screw	3
71	4.009.0031.32EVO	Ground cord	1
72	5.01.16.06001EVO	Shoulder screw	2
73	4.012.0051.09EVO	Pawl	2
74	4.012.0061.06EVO	Pawl spring	2
*	3.002.0030.15EVO	Short Block CSG 25-12 ES(2.4.5.6.7.8.9.10.11.12.13.14.15.16)	1
**	3.002.0030.151EVO	Cylinder-piston group( 11.12.13.14.16)	1



№	Артикул	Наименование	Кол-во
101	3.001.0401.02EVO	Decorative cover	1
102	3.001.0043.44EVO	Handle	1
103	4.009.0051.04EVO	Switch(on/off) cover	1
104	5.04.01.03091EVO	Φ3x9 Pin	2
105	5.04.01.03141EVO	Φ3x14 Pin	1
106	5.04.01.05281EVO	Φ5x28 Pin	1
107	4.008.0021.12EVO	Throttle spring	1
108	3.001.0201.16EVO	Throttle trigger	1
109	3.001.0211.16EVO	Throttle interlock arm	1
110	4.008.0031.09EVO	Throttle rod	1
111	3.001.0051.05EVO	Hand cover	1
112	4.008.0041.06EVO	Choke rod guide	1
113	3.001.0343.28EVO	Choker knob	1
114	4.005.0041.14EVO	Inlet pipe guide	1
115	4.017.0013.34EVO	Carburator MP13BZ3	1
116	3.001.0451.05EVO	Air filter seat	1
117	4.005.0241.09EVO	Air filter pad	1
118	5.01.03.39141EVO	ST3.9X14Screw	7
119	4.005.0053.11EVO	Air filter sponge	1
120	4.005.0211.02EVO	Air filter	1
121	3.001.0101.67EVO	Air filter cover	1
122	4.005.0161.03EVO	Lock button gasket	1
123	3.001.0321.07EVO	Lock button	1
124	3.001.0141.17EVO	Fan cover	1
125	4.005.0021.02EVO	Intake seat	1
126	4.012.0031.04EVO	Nylon ropeer	1
129	3.001.0241.07EVO	Starter knob	1
130	3.001.0131.04EVO	Starter cover Comp	1
131	4.504.0011.01EVO	Rope guide cover	1
132	4.012.0011.13EVO	Recoil spring	1
133	4.012.0013.08EVO	Recoil spring plate	1
134	4.012.0151.20EVO	Start reel	1
135	5.05.01.05161EVO	Φ5xΦ16x1 Washer	1
137	3.002.0003.85EVO	Starter Assy	1
138	3.001.0191.12EVO	Left handle	1
139	4.013.0181.02EVO	Safety belt	1
141	5.01.05.48162EVO	ST4.8X16Screw	5
142	3.001.0091.37EVO	Muffler cover	1
143	3.001.0123.15EVO	Front hand guard	1
144	4.011.0111.02EVO	Hook	1
145	4.011.0101.02EVO	Torsional spring	1
146	5.02.01.05001EVO	M5 Nut	1
147	4.011.0061.02EVO	Brake twist spring	1
148	5.01.13.0530EVO	M5X30 Screw	1
149	4.011.0141.11EVO	Pin sleeve	1
150	4.011.0141.12EVO	Pin bushing	1
151	3.001.0113.55EVO	Clutch cover	1
152	4.011.0141.13EVO	Brake limit cap	1
153	4.011.0011.08EVO	Brake limit spring	1
154	4.015.0041.02EVO	Tensioner pin	1
155	4.015.0021.02EVO	Tensioner passive bolt	1
156	4.015.0011.05EVO	Chain tension adjuster	1
157	4.015.0131.04EVO	Tension plater	1
158	3.001.0151.10EVO	Brake spring cover	1
159	4.011.0041.15EVO	Main lever	1
160	4.011.0041.16EVO	Sub lever	1
161	4.011.0041.08EVO	Brake arm	1
162	4.011.0011.09EVO	Brake spring	1
163	4.011.0031.09EVO	Brake band	1
164	3.002.0002.32EVO	Cluth cover Assy	1
165	5.02.09.08001EVO	M8 Nut	2
166	4.000.0061.03EVO	12-inch Guide Bar cover	1
167	4.016.0032.01EVO	Saw Chain JL9D-3-45(3/8-050G-45X)	1
168	4.016.0022.03EVO	Guide Bar 12-45-50-3/8	1
169	4.000.0111.06EVO	Nail board	1
170	5.01.02.39201EVO	ST3.9X20 Screw	1
171	5.01.05.48121EVO	ST4.8X12 Screw	1
*	3.002.0030.152EVO	Set (154.155.156)	1