



№	Артикул	Наименование	Кол-во
1	8006-750602-0317010EVO	Left Housing	1
2	8044-750601-0000130EVO	Switch trigger 2	1
3	8342-750605-0000000EVO	Handle lock button spring	1
4	8043-750601-0100110EVO	Lock push button	1
5	8342-750601-0000000EVO	Lock push button spring	1
6	8020-750701-0000130EVO	Decorative cover	1
7	233-1003EVO	Heat shrinkable tube	0
8	8326-750601-0100010EVO	Sponge mat	1
9	8144-750601-0000110EVO	base	1
10	8453-750602-0000130EVO	Long knife sleeve	1
11	8453-750601-0000110EVO	Short knife sleeve	1
12	199029000283EVO	Long Blade assembly	1
12-1	201045000354EVO	Lower blade	1
12-2	201045000355EVO	Upper blade	1
12-3	207190400005EVO	Blade pin	3
12-4	8RC04-08BEVO	Half round head rivet	3
12-5	8332-750602-0100030EVO	Blade sheath	1
13	199029000259EVO	Short Blade assembly	1
13-1	201045000286EVO	Lower scissors	1
13-2	201045000287EVO	Upper scissors	1
13-3	8086-750801-0100030EVO	Scissors fixing pin	1
13-4	8332-750802-0000030EVO	Scissors sheath	1
14	8440-750603-0000010EVO	Motor assembly	1
15	8440-750604-0000010EVO	Gearbox assembly	1
15-1	202005000025EVO	Gearbox	1
15-2	8202-750801-0000000EVO	Antifriction pad	2
15-3	8123-750802-0000000EVO	Double gear	1
15-4	8CE-04BEVO	Circlip	1
15-5	8123-750803-0100000EVO	gear	1
15-6	8SNAD2.5-06DEVO	Cross groove pan head flange screw	2
16	8006-750601-0217010EVO	right Housing	1
17	8SJAB30-12DEVO	Cross grooved pan head tapping screw	8
18	8SJAB25-07DEVO	screw	2
19	8414-750604-0000000EVO	Electronic components	1
20	233-1005EVO	Heat shrinkable tube	0
21	102007000011EVO	Battery pack assembly	1
22	8426-750606-0000000EVO	Charger	1
23	8020-750604-0000010EVO	Socket cover	1