



№	Артикул	Наименование	Кол-во
1	07.1.19.06.003EVO	BS Right Handle Welding	1
2	10.17.08.1.201EVO	Non metallic hexagonal lock nut	11
3	08.1.01.00.019EVO	Small tension plate convex pad	4
4	14.1.22.02.001EVO	Travelling handle tension spring	1
270	10.07.03.9.201EVO	Pan head square drill tail screw M3.5X10	4
6	10.06.05.1.203EVO	Cross recessed pan head bolt	2
11	10.14.05.1.201EVO	Outer hexagonal nut	2
12	10.04.08.1.205EVO	Cup head square neck bolts	4
13	10.03.08.1.201EVO	Hexagon socket flat round head screw	2
14	07.1.35.06.014EVO	S type heated right armrest welding	1
15	10.12.08.1.204EVO	Flat cushion	4
16	05.1.35.001EVO	Dual color handle ball	2
17	10.06.05.9.104EVO	Cross recessed pan head screws	2
18	10.09.05.9.101EVO	CAP NUT	2
19	09.1.35.03.004EVO	S-style BS walking handle	1
20	07.1.35.03.008EVO	Welding of S style snow outlet handle rod	1
22	10.02.08.1.202EVO	Outer hexagonal screw of flange face	4
24	10.12.08.1.203EVO	Flat cushion	2
25	14.1.09.02.001EVO	Handle adjustment spring 2.5	1
26	10.01.08.1.208EVO	Outer hexagonal bolt	1
27	11.1.19.003EVO	BS1400 snow outlet cable	1
28	08.1.19.00.005EVO	Conical tooth M2C20	1
29	08.1.19.00.004EVO	Conical tooth M2C18	1
66	10.01.06.1.201EVO	Outer hexagonal bolt	2
150	10.18.08.1.201EVO	Outer hexagonal flange nut	2
271	06.1.35.03.007EVO	Switch fixing seat	1
257	10.17.06.1.201EVO	Non metallic hexagonal lock nut	2
274	10.17.05.1.201EVO	Non metallic hexagonal lock nut	1
275	13.000.06.005EVO	Rectifier bridge	1
276	10.06.05.1.204EVO	Cross recessed pan head screws	1
30	03.1.35.45.01EVO	Steering handle assembly	2
7	05.1.10.1100EVO	handle	1
8	05.1.10.1200EVO	Handle seat	1
9	08.1.35.02.001EVO	Handle pin shaft	1
10	10.23.03.4.001EVO	split washer	1
11	10.14.05.1.201EVO	Outer hexagonal nut	1
32	03.1.22.36.00EVO	Self-locking component	1
33	11.1.19.002EVO	BS self-locking cable	1
34	12.1.19.00.101EVO	BS rocker damping sleeve	1
35	10.01.06.5.202EVO	Outer hexagonal bolt with spring washer	2
36	07.1.35.03.007EVO	Operation board welding	1
37	07.1.35.06.015EVO	S heated left armrest welding component	1
38	06.1.35.03.005EVO	Panel connection base 1 (right)	1
39	06.1.35.03.006EVO	Panel connection base 1 (left)	1
40	06.1.19.03.004EVO	BS bevel gear carrier	1
41	10.01.06.6.203EVO	Outer hexagonal flat washer bolt with spring washer	2
42	10.12.19.2.201EVO	Waveform elastic washer	1
43	10.23.20.1.001EVO	Shaft circlip	1
44	12.1.35.00.016EVO	New rubber sleeve 2	1
45-1	02.1.35.01.001EVO	CRAFTS panel components	
260	06.1.35.06.004EVO	Craftsman Main Panel	
262	12.000.00.121EVO	O-rings	1
263	03.1.35.35.01EVO	CRAFTS light assembly	
261-1	10.06.04.5.201EVO	Cross recessed pan head tapping screws	2
45	02.1.35.01.002EVO	Simpliciry panel components	
266	15.1.35.01.001EVO	SIM panel logo	
264	06.1.35.06.003EVO	Simpliciry Main Panel	
265	03.1.35.35.02EVO	SIM light assembly	1
21	10.06.02.5.201EVO	Cross recessed pan head tapping screws	6
261	10.06.04.5.201EVO	Cross recessed pan head tapping screws	8
23	12.000.00.122EVO	O-rings	2
46	13.1.10.04.003EVO	Ship type rocker waterproof switch	1
47	05.1.35.003EVO	Handlebar stopper	1
48	10.23.10.1.001EVO	Shaft circlip	1
49	10.12.10.9.001EVO	Flat cushion	2
50	05.1.35.004EVO	Rocker handle	1
51	08.1.22.03.003EVO	rocker	1
52	10.24.04.3.102EVO	Double ring elastic pin	1
53	12.1.35.00.015EVO	New rubber sleeve 1	1
54	06.1.19.06.002EVO	BS left handle	1
55	12.1.35.00.014EVO	Heating handle cover	2
89	10.12.08.5.201EVO	Concave gasket	2
267	10.07.08.1.211EVO	Concave bolt	2
25	14.1.09.02.001EVO	Handle adjustment spring 2.5	1
56	08.1.01.02.001EVO	SJ wire rod	2
273	10.08.05.1.101EVO	SJ copper nut	2
57	11.1.35.004EVO	8027-3 auger cable	1
58	11.1.35.007EVO	working cable	1
59	08.1.35.03.001EVO	450 gear shift connecting rod II	1
60	10.24.00.9.202EVO	BS plug	2
61	10.14.08.1.204EVO	Outer hexagonal nut	1
62	08.1.19.02.001EVO	Connecting rod adjustment sleeve	1
63	10.14.08.4.201EVO	M8 counter threaded external hexagonal nut	1
64	09.1.19.03.002EVO	1170 gear shift connecting rod	1
65	14.1.10.02.001EVO	Speed gap adjustment spring 1	1
66	10.01.06.1.201EVO	Outer hexagonal bolt	2
258	10.12.06.1.204EVO	Flat cushion	2
67	05.1.19.005EVO	8027-3BS belt cover	1
69	10.01.08.7.201EVO	External hexagonal combination screw with flat spring washer	4
3	08.1.01.00.019EVO	Small tension plate convex pad	1
70	09.1.01.03.014EVO	Small tensioning plate 2	1
71	10.01.08.1.204EVO	Outer hexagonal bolt	1
24	10.12.08.1.203EVO	Flat cushion	1
72	08.1.10.00.001EVO	Small tensioning wheel convex pad	1
73	03.1.17.10.00EVO	Small tensioning wheel assembly	1
74	08.1.01.00.012EVO	interlay	1
2	10.17.08.1.201EVO	Non metallic hexagonal lock nut	1
75	10.28.05.9.001EVO	flat key	1
76	09.1.35.03.005EVO	3BS belt stopper assembly	1
77	08.1.01.00.005EVO	SJ14 main synchronous wheel	1
78	10.16.10.002EVO	synchronous pulley	1
80	08.1.35.06.003EVO	8027-3BS main pulley	1
81	10.16.03.001EVO	V belt	1
82	08.1.35.02.007EVO	Belt pulley pressing block	1
83	10.13.04.205EVO	Washer	1
84	10.02.08.3.203EVO	Outer hexagonal flange bolt	1
85	14.1.01.02.001EVO	GPP small tensioning wheel tension spring	1
86	03.1.35.35.00EVO	8hp heating harness	1
87	07.1.35.06.002EVO	Lower armrest	1
88	05.1.22.100EVO	knob	4
89	10.12.08.5.201EVO	Concave gasket	4
90	10.07.08.1.214EVO	Concave bolt	4
2	10.17.08.1.201EVO	Non metallic hexagonal lock nut	16
91	10.01.08.1.204EVO	Outer hexagonal bolt	4
92	10.13.04.205EVO	Washer	10
93	09.1.09.03.001EVO	Fork arm	1
94	09.1.01.03.008EVO	SJ right angle iron block	1
95	10.24.06.3.101EVO	Roll elastic pin	2
96	07.1.35.03.014EVO	30 shift fork	1
97	10.01.06.5.201EVO	Outer hexagonal screw with spring washer	4
98	10.01.06.4.201EVO	Outer hexagonal screw with spring washer	28
99	09.1.35.03.002EVO	BS pulley mounting plate 1	1
100	05.1.01.100EVO	SJ pulley	3
101	10.07.06.1.211EVO	14 SJ screws 3	3
102	10.18.06.1.201EVO	Outer hexagonal flange nut	3
103	06.1.35.03.003EVO	BS pulley mounting plate 2	1
104	10.01.08.1.202EVO	Outer hexagonal bolt	3
105	05.1.33.002EVO	Right spacer sleeve of pawl	1
106	03.1.35.47.00EVO		1
107	06.1.35.03.002EVO	Pawl fixing block	1
108	08.1.10.00.020EVO	Clutch pawl	1
109	10.25.04.2.201EVO	Iron half hollow rivet	1
110	08.1.35.02.002EVO	pawl spring	2
111	08.1.35.02.003EVO	Short pawl shaft	1
112	03.1.35.47.01EVO		1
107	06.1.35.03.002EVO	Pawl fixing block	1
108	08.1.10.00.020EVO	Clutch pawl	1
109	10.25.04.2.105EVO	Iron half hollow rivet	1
113	06.1.35.03.004EVO	Claw rod support plate	1
114	10.12.08.1.205EVO	Flat cushion	3
115	10.15.07.2.010EVO	Deep Groove Ball Bearing with stop groove	2
116	08.1.33.00.006EVO	spacer	1
117	03.1.35.31.00EVO		2
118	08.1.33.00.004EVO	planet carrier	1
119	10.15.13.1.009EVO	drawn cup needle roller bearing	2
120	08.1.33.00.001EVO	Sun gear	1
121	08.1.33.00.002EVO	Planetary gear	3
122	10.15.13.1.008EVO	drawn cup needle roller bearing	1
123	08.1.33.00.003EVO	internal gear	1
124	10.12.16.1.201EVO	Flat cushion	2
125	08.1.33.04.002EVO	Differential shaft	1
126	10.28.05.1.005EVO	A-type flat key	1
127	10.12.14.1.201EVO	Flat cushion	1
128	10.23.14.1.001EVO	Shaft circlip	1
129	08.1.35.04.004EVO	24 tooth sprocket	1
130	10.12.10.1.206EVO	Flat cushion	1
131	10.17.10.1.201EVO	Non metallic hexagonal lock nut	2
132	03.1.19.21.00EVO	BS wheel bolt	2
133	03.1.35.13.00EVO		
134	09.1.33.03.006EVO	6004 bearing cover	2
135	10.15.07.1.036EVO	deep groove ball bearing	2
136	08.1.33.04.004EVO	Drive shaft left spacer sleeve	1
137	10.27.08.1.002EVO	08A Chain	2
138	08.1.35.04.001EVO	Sprocket 20Z	2
139	08.1.35.04.002EVO	1330 Left Drive Axle	1
259	08.1.35.04.003EVO	1330 Right Drive Axle	1
140	10.23.15.4.001EVO	split washer	2
141	10.28.05.4.002EVO	Semicircle key	2
142	10.15.14.001EVO	Flange Deep Groove Ball Bearing	2
143	08.1.35.02.004EVO	Drive shaft spring	2
144	08.1.33.04.003EVO	Drive shaft connecting sleeve	1
145	09.1.35.03.003EVO	Drive axle support bracket	1
146	10.01.08.6.201EVO	Outer hexagonal triple combination bolt	18
147	09.1.33.03.005EVO	Drive seat support plate	1
148	08.1.33.04.005EVO	Drive shaft right spacer sleeve	1
149	10.01.08.1.209EVO	Outer hexagonal bolt	1
15	10.12.08.1.204EVO	Flat cushion	14
150	10.18.08.1.201EVO	Outer hexagonal flange nut	5
151	07.1.35.06.010EVO	8027-3 gearbox	1
152	10.15.07.2.007EVO	Deep Groove Ball Bearing with stop groove	2
153	08.1.33.02.001EVO	Hexagonal axis	1
154	03.1.35.07.00EVO		1
155	10.23.35.1.001EVO	Shaft circlip	1
156	10.25.03.1.104EVO	Aluminum flat head rivet	4
157	10.15.07.1.007EVO	deep groove ball bearing	1
158	09.1.01.02.004EVO	SJ variable speed wheel axle cover	2
159	09.1.33.07.001EVO	variable speed wheel	1
160	08.1.17.00.002EVO	BS variable speed wheel	1
161	10.01.06.5.201EVO	Outer hexagonal screw with spring washer	3
97	10.27.08.1.007EVO	08A Chain	1
162	08.1.10.00.032EVO	Sprocket (Z10)	1
163	08.1.33.04.007EVO	Hexagonal shaft spacer sleeve	1
164	10.12.13.1.201EVO	Flat cushion	1
165	05.1.33.003EVO	Belt pulley bracket spacer sleeve	1
166	08.1.35.02.005EVO		1
167	10.24.02.1.201EVO		1
168	03.1.35.03.00EVO		1
169	08.1.01.00.011EVO	Friction disc return spring	1
170	08.1.01.00.009EVO	Large pulley cover	1
171	08.1.33.04.001EVO	Friction wheel axle	1
172	10.05.06.1.201EVO	Cross recessed countersunk head screws	6
173	10.15.08.1.009EVO	angular contact ball bearing	1
174	08.1.01.01.001EVO	Large pulley spacer sleeve	1
175	10.23.40.2.001EVO	Hole circlip	1
177	09.1.33.03.014EVO	Friction wheel bracket	1
178	10.17.10.2.201EVO	Non metallic hexagonal lock nut	1
176	09.1.33.03.001EVO	Bracket limit piece	1
179	03.1.35.13.01EVO		1
180	06.1.33.03.001EVO	Pulley mounting plate	1
257	10.17.06.1.201EVO	Non metallic hexagonal lock nut	1
181	10.01.06.1.209EVO	Outer hexagonal bolt	1
182	11.1.35.003EVO	clutch cable	2
183	09.1.35.06.002EVO	Small rear cover plate	1
184	09.1.33.06.001EVO	Rear cover	1
185	08.1.35.03.002EVO	260 hexagonal rotating rod	1
186	10.24.04.3.101EVO	Double ring elastic pin	5
187	08.1.10.03.010EVO	cardan joint	2
188	08.1.08.03.004EVO	280 Snow chute Rocker 1	1
189	08.1.22.03.001EVO	Steering lever 1	1
190	05.1.15.300EVO	Worm gear cover	1
191	10.19.06.1.201EVO	All metal hexagonal flange locking nut	1
192	08.1.15.00.001EVO	Snow outlet self-locking component III	2
193	10.01.06.1.115EVO	Outer hexagonal bolt	1
194	07.1.35.06.009EVO	Welding of large diameter pipes	1
195	06.1.19.03.002EVO	BS Worm Frame	1
196	10.04.08.1.204EVO	Cup head square neck bolts	2
197	08.1.22.02.001EVO	steering worm	1
201	10.12.06.1.201EVO	Flat cushion	1
198	14.1.22.02.002EVO	Snow outlet cap tension spring	1
199	07.1.35.06.005EVO	Welding with large snow chute	1
200	05.1.35.008EVO	1330 snow tube rubber	1
257	10.17.06.1.201EVO	Non metallic hexagonal lock nut	3
201	10.12.06.1.201EVO	Flat cushion	2
202	10.07.06.1.201EVO	Snow outlet bolt	1
203	07.1.35.06.006EVO	Welding of large snow discharge tube	1
272	10.03.06.5.201EVO	Large flat head hexagonal bolt	2
257	10.17.06.1.201EVO	Non metallic hexagonal lock nut	2
258	10.12.06.1.201EVO	Flat cushion	2
204	10.01.06.1.206EVO	Outer hexagonal bolt	3
102	10.18.06.1.201EVO	Outer hexagonal flange nut	2
205	14.1.01.02.004EVO	SJ Spring 4	1
206	09.1.19.02.001EVO	BS Security Kit	1
207	03.1.17.18.00EVO	BS plastic shield components	1
208	05.1.01.400EVO	Shovel seat	1
5	10.25.04.2.107EVO	304 half round head blind rivets	2
209	05.1.22.200EVO	Snow tube gasket	1
210	10.28.06.2.004EVO	B-type flat key	1
211	09.1.01.03.004EVO	SJ round bottom cover	1
212	10.15.11.1.002EVO	spherical bearing	1
213	10.01.08.1.202EVO	Outer hexagonal bolt	1
214	10.12.08.1.206EVO	Flat cushion	1
2	08.1.33.06.001EVO		