




№	Артикул	Наименование	Кол-во
1	07.1.19.06.003EVO	Traction drive engagement Lever,right	1
2	10.17.08.1.201EVO	Lock nut, Hex Head,non-metal	41
3	08.1.01.00.019EVO	Convex Pad,small idler plate	5
4	14.1.22.02.001EVO	Spring, drive handle	1
5	10.25.04.2.103EVO	Core Rivet	4
6	10.06.05.1.203EVO	Cross head bolt	2
7	05.1.10.1100EVO	Trigger	2
8	05.1.10.1200EVO	Trigger base	2
9	08.1.35.02.001EVO	Pin,Trigger	2
10	10.23.03.4.001EVO	split washer	2
11	10.14.05.1.201EVO	Outer Hexagonal NUT	2
12	10.04.08.1.205EVO	step bolt	4
13	10.01.08.1.207EVO	Hexgon Screw	2
15	10.12.08.1.204EVO	flat washer	18
17	10.06.05.1.202EVO	Cross head screw	2
18	10.17.05.1.201EVO	Lock nut, Hex Head,non-metal	2
21	10.06.02.5.201EVO	Cross head screw,self-tapping	6
22	10.02.08.1.201EVO		4
23	12.000.00.121EVO	O shape ring	2
24	10.12.08.1.203EVO	flat washer	15
25	14.1.09.02.001EVO	Spring 2.5	1
26	10.01.08.1.208EVO	Hexagon screw	1
27	11.1.19.003EVO	Chute cable	1
28	08.1.19.00.005EVO	Bevel gear M2C20	1
29	08.1.19.00.004EVO	Bevel gear M2C18	1
30	03.1.35.45.01EVO		
31	10.13.04.203EVO	Spring washer	2
32	03.1.22.36.00EVO	Self-lock ASSY.	1
33	11.1.19.002EVO	BS self-lock cable	1
34	12.1.19.00.101EVO	Damper bushing, rotation rod	1
35	10.01.06.1.208EVO	Hexagon screw	2
40	06.1.19.03.004EVO	BS bevel gear rack	1
41	10.01.06.6.203EVO	Screw,outer hex head,flat washer	2
42	10.12.19.2.201EVO	Wave spring washers)	1
43	10.23.20.1.001EVO	Jump Ring	1
44	12.1.22.00.101EVO	Rubber bushing 2	1
45	02.1.35.01.002EVO		
45-1	02.1.35.01.001EVO		
46	13.1.10.04.001EVO	10 switch	1
48	10.23.10.1.001EVO	Jump Ring	1
49	10.12.10.1.201EVO	flat washer	2
51	08.1.22.02.002EVO	Rotation lever	1
52	10.24.04.3.102EVO	spring pin,double ring	1
53	12.1.22.00.102EVO	Rubber bushing 1	1
54	06.1.19.06.002EVO	Auger drive engagement Lever,left	1
55	12.1.35.00.001EVO	Heated handle grip	2
56	08.1.01.02.001EVO	Steel rod+copper nut	2
57	11.1.35.001EVO	Auger cable	1
58	11.1.35.002EVO	Drive cable	1
59	08.1.35.03.001EVO	Connecting rod 2,shifting	1
60	10.24.00.9.202EVO	BS pin	2
61	10.14.08.1.204EVO	Outer Hexgon bolt	1
62	08.1.19.02.001EVO	Regulating sleeve,connecting rod	1
63	10.14.08.4.201EVO	Outer Hexgon bolt,M8 threaded	1
64	09.1.19.03.002EVO	connecting rod ,shifting	1
65	14.1.10.02.001EVO	adjusting spring 1	1
66	10.01.06.1.201EVO	Outer Hexagonal screw	2
67	05.1.33.001EVO	Belt cover	1
69	10.01.08.7.201EVO	Screw,outer hex head,flat washer	2
70	09.1.33.03.003EVO	Small idler plate	1
71	10.01.08.1.204EVO	Outer Hexagonal screw	1
72	08.1.10.00.001EVO	Convex Pad,small idler pulley	1
73	03.1.17.10.00EVO	Idler pulley ASSY.	1
74	08.1.01.00.012EVO	Washer	2
75	10.28.05.9.001EVO	Flat key	1
76	09.1.33.03.002EVO	Belt bar Assy.	1
77	08.1.35.00.001EVO	BS26 Synch-pulley	1
78	10.16.10.004EVO	Traction drive belt	1
79	08.1.01.00.004EVO	Cushion,small belt wheel	1
80	08.1.35.06.001EVO	SLXA main belt wheel	1
81	10.16.02.016EVO	Auger drive belt	1
83	10.13.04.206EVO	Spring washer	1
84	10.01.10.3.201EVO	Outer hexagon screw	1
85	14.1.01.02.002EVO	Sping 5	
86	03.1.35.35.00EVO	Heated wire harness	1
87	07.1.35.06.002EVO	Lower handle	1
88	05.1.22.100EVO	Knob	4
89	10.12.08.5.201EVO	Concave gasket	6
90	10.07.08.1.214EVO	Concave screw	6
91	10.01.08.1.204EVO	Outer hexagon screw	4
92	10.13.04.205EVO	Spring washer	8
93	09.1.09.03.001EVO	Shift fork Arm	1
94	09.1.01.03.008EVO	Shift fork base	1
95	10.24.06.3.101EVO	spring pin	2
96	09.1.35.03.001EVO	30 shift fork	1
97	10.01.06.5.201EVO	Screw,outer hex head,spring washer	7
98	10.01.06.4.201EVO	Screw,outer hex head,flat washer	30
99	09.1.35.03.002EVO	Pulley Mounting plate(1)	1
100	05.1.01.100EVO	Cable pulley	3
101	10.07.06.1.211EVO	Nut bolt 3	3
102	10.19.06.1.201EVO	Flange screw,hexgon	5
103	06.1.35.03.003EVO	Pulley Mounting plate(2)	1
104	10.01.08.1.202EVO	Outer Hexgon bolt	3
105	05.1.33.002EVO	Pawl sleeve,right	1
106	03.1.35.47.00EVO	Pawl assy.,right	1
107	06.1.35.03.002EVO	Pawl fixed block	1
108	08.1.10.00.020EVO	Clutch pawl	1
109	10.25.05.2.201EVO	Steel semitubular rivet	1
110	08.1.35.02.002EVO	Pawl spring	2
111	08.1.35.02.003EVO	Pawl shaft	1
112	03.1.35.47.01EVO	Pawl assy.,left	1
107	06.1.35.03.002EVO	Pawl fixed block	1
108	08.1.10.00.020EVO	Clutch pawl	1
109	10.25.05.2.201EVO	Steel semitubular rivet	1
113	06.1.35.03.004EVO	Pawl lever brace slice	1
114	10.12.08.1.205EVO	flat washer	3
115	10.15.07.2.010EVO	Deep groove ball bearing	2
116	08.1.33.00.006EVO	Space ring	1
117	03.1.35.31.00EVO	Clutch ASSY.	2
118	08.1.33.00.004EVO	Planet wheel bracket	1
119	10.15.13.1.008EVO	Needle roller bearing	2
120	08.1.33.00.001EVO	Sun wheel	1
121	08.1.33.00.002EVO	Planet wheel	3
122	10.15.13.1.009EVO	Needle roller bearing	2
123	08.1.33.00.003EVO	Internal gear	1
124	10.12.16.1.201EVO	flat washer	2
125	08.1.33.04.002EVO	Differential shaft	1
126	10.28.05.1.012EVO	Plain key,A shape	1
127	10.12.14.1.201EVO	flat washer	1
128	10.23.14.1.001EVO	Circlips forshaft	1
129	08.1.35.04.004EVO	24 tooth sprocket	1
130	10.12.10.1.206EVO	flat washer	1
131	10.17.10.1.201EVO	Lock nut, Hex Head,non-metal	2
132	03.1.19.21.00EVO	Klik pin	2
133	03.1.35.13.00EVO	Tire Assembly,left	
134	09.1.33.03.006EVO	6004 bearing cover	2
135	10.15.07.1.036EVO	Deep groove ball bearing	2
136	08.1.33.04.004EVO	left sleeve,Drive shaft	1
137	10.27.08.1.002EVO	08A chains	2
138	08.1.35.04.001EVO	sprocket wheel (20Z)	2
139	08.1.35.04.002EVO	1330 left driving wheel axle	1
140	10.23.15.4.001EVO	split washer	2
141	10.28.05.4.002EVO	woodruff key	2
142	10.15.14.001EVO	Flange Deep groove ball bearing	2
143	08.1.35.02.004EVO	spring,Drive shaft	2
144	08.1.33.04.003EVO	Connecting sleeve,Drive shaft	1
145	09.1.35.03.003EVO	Support frame,driving wheel shaft	1
146	10.01.08.6.201EVO	Outer hexagon screw	18
147	09.1.33.03.005EVO	support plate	1
148	08.1.33.04.005EVO	right sleeve,Drive shaft	1
149	10.01.08.1.209EVO	Screw,Hex head	1
150	10.18.08.1.201EVO	Flange screw,hex head	5
151	09.1.35.06.001EVO	Motor box	1
152	10.15.07.2.007EVO	Deep groove ball bearing	2
153	08.1.33.02.001EVO	Hexagonal shaft	1
154	03.1.35.07.00EVO		1
155	10.23.35.1.001EVO	Shaft circlip	1
156	10.25.03.1.104EVO	Aluminum flat head rivet	4
157	10.15.07.1.007EVO	Deep groove ball bearing	1
158	09.1.01.02.004EVO	Friction wheel shaft cap	2
159	09.1.33.07.001EVO	Friction wheel	1
160	08.1.17.00.002EVO	BS Friction wheel	1
161	10.27.08.1.007EVO	08A chains	1
162	08.1.10.00.032EVO	Chain wheel	1
163	08.1.33.04.007EVO	Bushing,hexagon shaft	1
164	10.12.13.1.201EVO	flat washer	1
165	05.1.33.003EVO	spacer sleeve,Belt pulley bracket	1
166	08.1.35.02.005EVO	Reset spring,Friction disk	1
167	10.24.02.1.201EVO	splitpin	1
168	03.1.33.07.00EVO		1
169	08.1.01.00.011EVO	larger drive disk	1
170	08.1.01.00.009EVO	cover,larger drive disk	1
171	08.1.33.04.001EVO	Friction wheel shaft	1
172	10.06.06.1.201EVO	Bolt,Phill head	6
173	10.15.07.1.021EVO	angular contact ball bearing	1
174	08.1.01.01.001EVO	spacer sleeve,larger drive disk	1
175	10.23.40.2.001EVO	Circlip	1
176	09.1.33.03.001EVO	Bracket limit	1
177	07.1.33.03.001EVO	Friction wheel bracket	1
178	10.17.10.2.201EVO	Lock nut, Hex Head,non-metal	1
179	03.1.35.13.01EVO		1
180	06.1.33.03.001EVO	Mounting plate,pulley	1
181	10.01.06.1.210EVO	Screw,Hex head	1
182	11.1.35.003EVO	cable,clutch	2
183	09.1.35.06.002EVO	Motor box cover,Smaller size	1
184	09.1.33.06.001EVO	Motor box cover,Larger size	1
185	WCM00000S19002EVO	STG1330-089	
186	10.24.04.3.101EVO	Double ring elastic pin	5
187	08.1.10.03.010EVO	universal coupling	2
188	WCM00000S19003EVO	STG8062Ae-101	Q235
189	08.1.22.03.001EVO	chute steering rod	1
190	05.1.15.300EVO	Chute worm cover	1
191	10.19.06.1.201EVO	lock nut	1
192	08.1.15.00.001EVO	self-lock assembly 3	1
193	10.01.06.1.207EVO	Screw,Hex head	1
194	ZPS000S48021EVO	STG1330-060H	
195	06.1.19.03.002EVO	worm bracket	1
196	10.04.08.1.204EVO	square Neck bolt,Cup head	2
197	08.1.22.02.001EVO	worm,Steering	1
198	14.1.22.02.002EVO	tensioned spring,chute deflector	1
199	07.1.35.06.005EVO	chute deflector weldment	1
200	06.1.35.00.011EVO	1330 Chute Rubber pad	1
202	10.07.06.1.201EVO	Screw,chute	1
203	07.1.35.06.006EVO	Chute weldment	1
204	10.01.06.1.206EVO	Screw,Hex head	3
205	14.1.01.02.004EVO	SJ Spring 4	1
206	09.1.19.02.001EVO	safty shelf assembly	1
207	05.1.01.1200EVO	Plastic Shovel	1
208	05.1.01.400EVO	Shovel Base	1
5	10.25.04.2.103EVO		2
209	05.1.22.200EVO	Chute Ring	1
211	09.1.01.03.004EVO	round bottom cover	1
212	10.15.11.1.001EVO	Ball bearing	1
213	10.01.08.1.210EVO	Screw,Hex head	1
214	10.12.08.1.206EVO	flat washer	1
215	08.1.33.06.001EVO	Driven pulley,5LXA	1
216	03.1.17.12.00EVO	Large idler pulley	1
217	08.1.01.00.017EVO	Washer sleeve	1
218	10.01.08.1.205EVO	Screw,Hex head	1
219	09.1.33.03.004EVO	Large idler Plate	1
220	10.12.10.1.203EVO	flat washer	1
221	10.01.10.1.204EVO	Screw,Hex head	1
222	14.1.35.02.001EVO	spring,idler Plate	1
223	06.1.01.03.005EVO	Backup Bar,Belt	1
224	10.04.08.1.205EVO	square Neck bolt,Cup head	2
225	07.1.35.06.008EVO	Auger housing weldment	1
226	10.04.08.1.201EVO	square Neck bolt,Cup head	11
227	09.1.01.06.009EVO	Skid shoe	2
228	09.1.35.06.003EVO	30"Housing scrapper Bar	1
229	10.07.06.1.213EVO	Fixed screw,Impeller	2
230	09.1.22.06.001EVO	Impeller blades weldment	1
231	08.1.22.04.001EVO	worm shaft	1
232	10.22.20.2.002EVO	Oil seal	1
233	10.15.06.1.003EVO	Single thrust ball bearing	1
234	10.12.20.1.201EVO	spacer	1
235	10.15.07.1.008EVO	Deep groove ball bearing	1
236	10.15.07.1.037EVO	Deep groove ball bearing	1
237	10.07.10.1.201EVO	Oil nipple	1
238	10.12.10.2.101EVO	corrugated gasket	1
239	08.1.01.00.006EVO	right Gear box	1
240	10.06.05.1.201EVO	Bolt,Phill head	1
241	08.1.01.00.031EVO	worm gear	1
242	08.1.01.00.007EVO	Left Gear box	1
243	10.22.19.1.001EVO	Oil seal	2
244	10.01.06.6.201EVO	combined bolt	6
245	10.01.06.6.202EVO	combined bolt	1
246	06.1.35.03.001EVO	Auger Shaft	1
247	10.28.05.4.002EVO	woodruff key	1
248	10.12.19.1.203EVO	flat washer	4
249	05.1.01.1000EVO	sleeve,Driven shaft	4
250	09.1.35.06.004EVO	Auger,Right	1
251	09.1.35.06.005EVO	Auger,Left	1
252	10.07.08.1.205EVO	Auger Shear Bolt	2
253	08.1.22.00.002EVO	Washer sleeve,Auger	2
254	08.1.15.00.002EVO	Auger base	2
255	05.1.15.500EVO	Nylon bearing,auger	2
无	16.1.02.001EVO		0,017
256	07.1.22.03.004EVO	support plate,Auger housing	1
257	10.17.06.1.201EVO	Lock nut, Hex Head,non-metal	9
258	10.12.06.1.204EVO	flat washer	7
259	08.1.35.04.003EVO	STG1330-003	45#
261	10.06.04.5.201EVO	Cross head screw,self-tapping	6
261-1	10.06.04.5.201EVO	Cross head screw,self-tapping	2
262	12.000.00.121EVO	1	
263	03.1.35.35.01EVO		